

BFM® – fitting guideline

Make sure to inspect your BFM® connector as well as the inside of the spigot before each installation and check for damages or product / cleaning agent residues.



Step 1

Push the snap ring of the connector together ("kidney shape") and set the seal with the two rings into the back of the spigot. Then let the connector snap into the ring profile of the spigot..



Step 2

Should the seal not snap out all around the spigot, push the snap ring to the inside at a different spot around the circumference of the connector. Repeat this step if necessary until the connector has snapped into the spigot all around.



Ready!

Take care that the white snap ring is completely embedded into the spigot (not one ring only!). The connection is then closed-off dust-tight.

This document does not imply any legally binding assurance concerning specific properties of the BFM® fittings or the suitability for a particular application. The responsibility of complying with any governing laws and regulations relevant to the use of BFM® fittings is the obligation of the user. Subject to technical changes without prior notice. BFM® is a registered trademark of BFM Global Ltd.

Walter Gerätebau GmbH / Neue Heimat 16 / 74343 Sachsenheim-Ochsenbach
T +49 7046 980-0 / info@walter-cleaningsystems.de / www.walter-cleaningsystems.de